



Substrate Preparation

ArmourColor

1 General Requirements

All substrates to receive ArmourColor shall be sound, crack-free, dust-free, flat, and smooth (equivalent to a drywall level 5) and free of surface contaminants and defects.

2 Recommended Substrates

Drywall: To be prepared to a minimum of a Level 5.

Brick, Block, CMU, & Precast: Prepare as to receive a high-sheen paint coating (level 5).

Previously Painted: Test for bond and load bearing strength and prepare to conform to the general requirements (level 5). For glossy paints lightly sand surface to remove surface luster. This recommendation is for waterbased paint systems only.

MDF Panels: Apply 2 coats of Sherwin Williams Preprite Wall & Wood Primer B49W2, or equivalent oil-based wood primer to all six sides of the panels and allow to dry. All MDF panels are to be at least 3/4" in thickness.

Build quality is the responsibility of the General Contractor.

For other substrates please contact the Technical Dept.
at: technical@armourcoat.co.uk

Whilst every attempt has been made to ensure the accuracy and reliability of the information contained in this document, the information should not be relied upon as a substitute for formal advice. Armourcoat Ltd, its employees and agents will not be liable for any loss or damage, of any kind, arising out of or in connection with the use of this document. Please refer to the company disclaimer for further details.

SAT 0609©

Armourcoat Limited
4330 Production Court
North Las Vegas NV 89115
Tel: 702 644 0601
Fax: 702 644 0554
Email: sales@usa.armourcoat.com

web: www.usa.armourcoat.com